

IP65 Waterproof Projector 4GOBO/8GOBO Instructions




60-150w 4P IP65




30-40w 4P IP65

1、Change gobo



2、Setting lamps



Rest ... Self-check of boot-up system
About 15 seconds later: (Main menu)

» Mast Mode:off/on

Address:001-511
Gobo set up
Gobo Number:1/2/3/4
Play Mode:RMT/Auto/MAN.
Play Dir:Right/Left
Play Speed:06
Black Dim:05
Black Dly:10

ON:Set up as host, OFF:Set up as subsidiary
Set DMX512
Set the display time of each gobo
Remote control/Auto/Manual control.
Set gobo display direction.
Set gobo switch speed.(Recommended range:05-07)
Set the brightness of the LED screen(01-10).
Set the Screen brightness display time.(01-30s)

For example

Next /+ Previous/-
Switching Main Menu

Mast Mode:off/on
Address:001-511

» Gobo set up

Set Gobo1: (1-99s optional)
Set Gobo2: (1-99s optional)
Set Gobo3: (1-99s optional)
Set Gobo4: (1-99s optional)

Press once: confirm
Press twice:Return to the previous level